

ACT 3-Series (Discontinued 600-band 8ch & 16ch versions)**

6A (620~644MHz) TV Channels 39-42	6B (644~668MHz) TV Channels 43-46	6C (668~692MHz) TV Channels 47-50
--------------------------------------	--------------------------------------	--------------------------------------

ACT 3-Series (Current 500- & 900-band version)

5A (506-530) TV Channels 20-23	5NC (also 5EA) (542~566MHz) TV Channels 26-29	5ND (566~590MHz) TV Channels 30-33	9NA (904-928MHz)
-----------------------------------	--------------------------------------------------	---------------------------------------	------------------

ACT 7-Series (Discontinued)**

N/A	5US (554~626MHz) TV Channels 28-39	6UA (626~698MHz) TV Channels 40-51
-----	---------------------------------------	---------------------------------------

ACT 7-Series

5UA (482~554MHz) TV Channels 16-27	5NU (554~608MHz) TV Channels 28-36	N/A
---------------------------------------	---------------------------------------	-----

ACT 8-Series (Discontinued)**

N/A	N/A	6E (636~700MHz) TV Channels 42-52
-----	-----	--------------------------------------

ACT 8-Series

5E (480~544MHz) TV Channels 16-26	5F (540~604MHz) TV Channels 26-36	N/A
--------------------------------------	--------------------------------------	-----

MI-808T/R (Discontinued)**

6A (620~644MHz) TV Channels 39-42	6B (644~668MHz) TV Channels 43-46	6C (668~692MHz) TV Channels 47-50
--------------------------------------	--------------------------------------	--------------------------------------

MI-909T/R

5E (480~544MHz) TV Channels 16-26	5F (540~604MHz) TV Channels 26-36	N/A
--------------------------------------	--------------------------------------	-----

MRM-70B

5A (506-530) TV Channels 20-23	5NC (542~566MHz) TV Channels 26-29
--------------------------------	------------------------------------

MR-90 (Discontinued)**

6A (620~644MHz) TV Channels 39-42	6B (644~668MHz) TV Channels 43-46	6C (668~692MHz) TV Channels 47-50
--------------------------------------	--------------------------------------	--------------------------------------

ACT-707S/ACT-707D, ACT-707SE/ACT-707DE, ACT-707F (Discontinued)**

6A (620~644MHz) TV Channels 39-42	6B (644~668MHz) TV Channels 43-46	6C (668~692MHz) TV Channels 47-50
--------------------------------------	--------------------------------------	--------------------------------------

ACT-81/ACT-82 (Discontinued)**

6A (620-644MHz) TV Channels 39-42	6B (644~668MHz) TV Channels 43-46	6C (668~692MHz) TV Channels 47-50
--------------------------------------	--------------------------------------	--------------------------------------

ACT-7Ha & ACT-7Ta transmitters (Discontinued 36MHz version)**

5UA1 (482~518MHz) TV Channels 16-21 5UA2 (518~554MHz) TV Channels 22-27	5US1 (554~590MHz) TV Channels 28-33 5US2 (590~626MHz) TV Channels 34-39	6UA1 (626~662MHz) TV Channels 40-45 6UA2 (662~698MHz) TV Channels 46-51
----------------------------------------------------------------------------------	----------------------------------------------------------------------------	----------------------------------------------------------------------------------